



W L I V E

CLJT004 Trash can

V1.0

Please be sure to properly save the manual for confirmation at any time.


Before using, please carefully read the manual and use it on the basis of full understanding.

⚠ Precautions for Use ⚠

1. To avoid potential danger of suffocation, keep all packaging (films, plastic bags or foam, etc.)away from babies and children.
2. Please don't exceed the max. loading capacity (each inner bucket:50kgs) or it may cause the damage.
3. Never put inflammables into the trash can or it may cause the damage and/or fire.
4. Avoid your children or pets playing with the pedal or other moving parts or it may cause the damage or injury.
5. Never use abrasive cleaning ball to clean the surface to avoid damaging the surface.

③

Before using the trash can, please take out the inner bucket and remove the wrapping paper at the bottom of the trash can.



②

Loose your foot and the lid will close slowly.


①

Step on the pedal to open the lid.



④

Take out the inner bucket, place the trash bag in the inner bucket, put the edge of the bag over the edge of the can and cram the surplus bag into the hole on the inner bucket.



⑤

Ready for use now!

